

CLAFFEY
POOLS

**HOW TO
WINTERIZE YOUR
AUTOFILL**



WINTERIZING YOUR AUTOFILL

HOW TO WINTERIZE YOUR AUTOFILL

1

STEP 1

Locate the autofill shutoff in yard. They are typically installed underneath an insulation bag and located near the pool equipment.

2

STEP 2

Lift the insulation bag - exposing the RPZ shutoff valve. Turn all brass handles 90 degrees to shut off water flow.

3

STEP 3

Put the insulation bag back over the rpz unit.

STEP 1

Locate the autofill shutoff in yard. They are typically installed underneath an insulation bag and located near the pool equipment.



STEP 2

Lift the insulation bag - exposing the RPZ shutoff valve. Turn all brass handles 90 degrees to shut off water flow.



STEP 3

Put the insulation bag back over the rpz unit.



CLAFFEY POOLS

CLAFFEYPOOLS.COM



WINTERIZING YOUR AUTOFILL