

## WaterColors Color Modes

14 Color Modes

Color Sequence



Alpine White



Sky Blue



Cobalt Blue



Caribbean Blue



Spring Green



Emerald Green



Emerald Rose



Magenta



Violet



Slow Color Splash



Fast Color Splash



America the Beautiful



Fat Tuesday



Disco Tech

## WaterColors Operation

**Changing Color Mode:** From ON, Turn the light OFF, then ON again within 3 seconds.

**Reset to Alpine White:** From ON, turn the light OFF, then wait 5 seconds to turn the light ON again.

**NOTE:** If off for more than 7 seconds, light will return to last used color when turned on again.

For the best experience, and direct color selection, ask your pool pro about AquaLink<sup>®</sup> pool and spa controls.

